

## EASY TO APPLY...



1



6



2



7



3



8



4



9



5



10

### STEPS 1 - 6

Apply paste to all vertical and horizontal joints using a brush.

Granfix membrane tape must then be applied to all the joints while paste is still wet.

### STEPS 7 - 8

Paste and tape must also be applied to all the intermediate walls and floors.

### STEPS 9 - 10

Overcoat the entire wall and floor surfaces and leave to dry thoroughly before applying a second coat.