

Installation Manual of Hand Bidet Set

Installation Step

1. Turn off water feed
2. Disconnect toilet hose from flush tank
3. Connect T-valve to flush tank
4. Connect toilet hose to T-valve
5. Connect shower hose to T-valve
6. Connect other end of shower hose to sprayer
7. Turn water feed back on
8. Screw wall bracket to wall

Notes

- Hand tighten connections
- **Do not** over tighten connections!
- Make sure washers are placed in T-valve and shower hose

Part List

- Sprayer
- Shower hose
- T-valve
- Wall bracket

