
5 Tier Wall Towel Rack Assembly

instructions

Product Size:

310mm W x 150mm D x 570mm H

Ref No: 052.02.050 chrome & 052.95.052 black version.



If you need help or have damaged or missing parts, call the Customer Helpline: 0121 776 5720

▲ Safety and care advice

Important-Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 3 and 4.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to lay out the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

• When drilling walls check first for hidden pipes and cables.

•Use safety eyewear when drilling.


Care and Maintenance

• Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners. • From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Handy Hints


• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts • Regularly check and ensure that all bolts and fittings are tightend properly.




Components supplied(not actual size)			
Ref	Dimensions(mm)	Image	Qty
1	39*39*18 mm		4
2	18*18*264 mm		2
3	18*18*524 mm		2
4	310*132*18 mm		5









A guide to wall mounting & fixings

Important note:

If plastic wall plugs are supplied with your product, these are only suitable for use in masonry walls.

e.g.:




If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.


Types of walls

No.1 "General Purpose" wall plug



Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug



For use when attaching light loads onto plasterboard partitions.



Important: when drilling into walls always check that there are no hidden wires or pipes etc.


Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

- 1: General rule: A always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.3 "Cavity Fixing" wall plug



For use with plasterboard partitions or hollow wooden doors.


No.4 "Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.


Safety: always check the fitting and location to ensure your safety in and around the home.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug heavy loads



For use with heavier loads such as TV and HiFi speakers and satelite dishes etc.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.