

Thermostatic Shower Mixer System Installation





Specifications

Dynamic Water Pressure Min:0.2 bar Max:6.0 bar






Maximum Static Pressure: 10.0 bar

Inlet Water Temperature
Cold Water Supply



Min: 5°C Max: 25°C


Hot Water Supply





65°C Recommended




The inlet hot water must be at least 10°C above the required blend temperature.













Maintenance-Cleaning check valve & mesh filter








Maintenance-Cleaning check valve & mesh filter



Maintenance-Cleaning Thermostatic Cartridge



TECHNICAL DATA

- 1.Standard Pressure: Dynamic water pressure Min: 0.2bar, Max:6.0bar
- 2.Cold Supply Temperature: 4-29°C; Hot Supply Temperature: 55-58°C;
- 3. Thermostatic Temperature Range: 20-50°C.
- 4.Pre-set Temperature: 38°C.
- 5.Safety Mechanism: The mixed water will be immediately cut off when the cold supply is not effective.
- 6.Precise Temperature: It takes approximately 5 seconds to achieve the desired temperature. The actual working temperature will be within $\pm 2^{\circ}$ C of the temperature.
- 7.Temperature Stability: The outlet temperature variation will be within $\pm 2^{\circ}$ C when the inlet temperature is stable and the hot and cold pressure varies by 50%. The outlet temperature variation will be within $\pm 2^{\circ}$ C when the inlet pressure is stable and the hot supply temperature increases from 60° C to 75° C(5° C/min).

Cleaning All surfaces should be cleaned using a clean damp cloth.

No abrasive cleaning agebts or materials should be used.