

shower arm

This shower arm is intended to be used in conjunction with other products, such as shower or blending valves, diverter, stopcocks and shower roses

COMPONENTS

1. Shower arm
2. Shroud
3. Backnut(optional)

INSTALLATION

The shower arm should be arranged in your system to accept a supply of flow controllable mixed water.

1. Identify all components, study diagram and check for completeness, particularly before arranging fitting.
2. The arm (1) is most suitable for mounting via the backnut (3) either side of a panel and/or tiles. However it is possible to support the arm using rigid pipework by connecting via a female G 1/2" BSP to 15mm compression adaptor. The 15mm pipework can then be adjusted to offer the necessary depth and vertical positioning for the eventual shower fixed head.

NOTE: Before finishing wall turn on water supplies to check for leaking from joints/connections.

3. Slide on shroud and connect arm to supply using thread sealing compound where necessary.

4. Complete wall finish and slide shroud (2) up to wall.

